SAFETY RECALL

HAMILTON BEACH & PROCTOR-SILEX TOASTERS

Model 22145B, 22145BC & 22450 	Model 22559 	Model 22625 & 22627C 
Model 22635 	Model 22657, 22658 & 22779 	Model 22900, 22903 & 22903H 
Model 24450 	Model 24559 	Model 24657 & 24779 

HEATING ELEMENTS MAY STAY ON AFTER TOASTER POPS UP, CREATING A POTENTIAL FIRE HAZARD. IMMEDIATELY STOP USING THE RECALLED TOASTER.

This recall involves certain toasters sold from August 2007 through February 2008.

CALL TOLLFREE 800.574.6800 ANY TIME, OR GO TO www.hamiltonbeach.com or www.proctorsilex.com TO LEARN IF YOUR TOASTER IS SUBJECT TO THIS RECALL AND HOW TO RECEIVE A FREE REPLACEMENT TOASTER.

In Cooperation with the U.S. Consumer Product Safety Commission

Post until July 31, 2008